



If GD connects to the IRS2092 ground anywhere, the middle rows of caps are shorted out, and the circuit is equivalent to this

←  
It will work fine, but the middle rows of caps do nothing